

Cleaning recommendation noraplan[®] wall

General instructions for professional cleaning of noraplan wall coverings

- Initial cleaning must be carried out after completion of the adhesive's bonding phase, at least 48 hours after installation.
- Use cleaning and polishing agents from a specially designed manufacturer range. Observe the instructions in the product and safety data sheets for the cleaning and polishing products used. Do not use any cleaning agents with a pH higher than 12.
- Do not use any green, brown or black pads.
- Areas exposed to intense sunshine require increased application of polishing agent.
- Depending on the premises, it may be useful to use products and processes that differ from the standard, but as per the wash polish manufacturer's recommendations. In doing so, sufficient self-tests must be carried out in order to ensure that the cleaning measures, materials and machines meet the special requirements.
- Cleaning should always be carried out according to the specifications of the professional building cleaners' association or the methods taught in the building cleaners' trade.

Routine cleaning & polishing

Damp-wipe with a spray-dampened or prepared cleaning cloth. Adhesive water-soluble or emulsifiable contaminations are removed by wet mopping. We recommend periodic cleaning with a cleaning agent that is diluted with water in a higher concentration. Then rinse with clear water. Select the pH value of the cleaning agent depending on the type of soiling: alkaline for organic soiling, acidic for limescale and rust. Steam cleaning is also a suitable cleaning method. Hand pads (red, e.g. 3M) can be used for heavy soiling.

Cleaning & polishing agents as well as stain removal

The cleaning and polishing products for noraplan floor coverings as well as stain tables and special cleaners listed on our website can also be used for noraplan wall coverings.

If you have any further questions, please contact nora tech department.